



## 05APO

- 1-Remove pipe & airbox, then remove primary air plenum.
- 2-Once primary plenum is removed, carefully cut stock air body couplers away from primary plenum.  
\*note-these couplers are glued on, so be cautious
- 3-Place Fire n Ice offset couplers on air bodies, then re-install primary plenum.  
\*note-new couplers are marked inside PTO & MAG
- 4-Replace pipe & airbox, insuring a minimum of 3/8" between pipe and airbox. Adjust if necessary.

Fire n Ice Performance Products, LLC  
860 Cranmer Ave.  
Idaho Falls, ID 83401  
[info@firenice.us](mailto:info@firenice.us)  
[sales@firenice.us](mailto:sales@firenice.us)  
[firenice.us](http://firenice.us)