



07AHK

- 1-Expose airbox top and underside of airshelf without any foam or attachment devices in place.
- 2-Tape supplied pattern to top of airbox over existing cutout.
- 3-Set airhorn on top of airbox pattern and close hood.
- 4-Adjust airhorn to match cutout in airshelf. Mark location of airhorn on pattern.
- 5-Tape airhorn to pattern.
- 6-Remove airbox, make appropriate cuts in airbox and airshelf.
- 7-With airhorn taped to airbox, use .250" bit to drill six attachment holes.
- 8-Use six .250" buttons to attach airhorn to airbox.
- 9-Replace foam over airhorn, insuring that when hood closes no airleaks exist around foam.



Fire n Ice Performance Products, LLC
860 Cranmer Ave.
Idaho Falls, ID 83401
info@firenice.us
sales@firenice.us
firenice.us