

FIRE N ICE

07CSAI

- 1-Open hood-cover airbox inlet then remove air shelf under instrument pod to expose stock air intakes.
- 2-Remove stock air intake filter pillow's and frames.
- 3-Holding 07CSAI on existing cutout, mark one hole. Drill with #20 (.161") bit.
*warning-drilling a larger hole will cause attachment buttons to fall out
- 4-Place product in place and put one button into previously drilled hole.
- 5-Holding combo side intake in place, drill another button hole for side intake.
- 6-Using template provided, mark side intake cutout as shown. Drill 1/2" holes as shown in pix.
- 7-Cut opening as shown in pix.
- 8-Hand shape air intakes to fit and install using supplied buttons.
- 9-Replace air shelf.



Fire n Ice Performance Products, LLC
860 Cranmer Ave.
Idaho Falls, ID 83401
info@firenice.us
sales@firenice.us