



08SAI

- 1-Open hood-cover airbox inlet then remove air shelf under instrument pod to expose stock air intakes.
- 2-Remove stock air intake filter pillow's and frames.
- 3-Holding 08SAI over existing cutout, mark one button hole and drill with #20 (.161") bit.
*warning-drilling a larger hole will cause attachment buttons to fall out
- 4-Place product on and put one button into previously drilled hole.
- 5-With intake in place, mark and drill remaining 5 button holes.
- 6-Using supplied pattern, mark and remove cutout area.
- 7- Install product using supplied buttons.
- 8-Repeat process on opposite intake.
- 9-Replace air shelf.



note: install procedure is the same with 05-07CSAI or 08SAI.

Fire n Ice Performance Products, LLC
860 Cranmer Ave.
Idaho Falls, ID 83401
info@firenice.us
sales@firenice.us
firenice.us