



07TLB

- 1-Remove stock taillight and hanger bracket. Re-mount tail light in supplied bracket with provided hardware. Remove seat base, then remove short pigtail from wire harness. Cut and remove 3 pin wire connector 2" back. Using supplied wire and butt splices, reconnect color coded wires.
- 2-Locate existing hole thru top of tunnel just under seat base. Insert wires thru hole and re-assemble seat.
- 3-Hold wire loom on top center of tunnel and drill 3/16" holes. (loom will rivet to inside of tunnel)
*note-wire loom does not cover entire length of wire—leave approx. 2"-3" gap in center.
- 4-Once holes are drilled for loom, a 1/4" hole must be drilled NEXT to rear "U" cooler crossover. Position tail light housing over 4 existing pop rivets and remove rivets. Mark for 1/4" hole being very careful not to drill into "U" cooler crossover.
- 5-Pull wires thru hole-snug and tape to tunnel.
- 6-With wires inside loom, pop rivet wire loom to tunnel. Use tape around wires where they go thru tunnel.
- 7-Using butt splices, attach color coded wires to tail light.
- 8-Attach new tail light to tunnel with supplied pop rivets.



Fire n Ice Performance Products, LLC
860 Cranmer Ave.
Idaho Falls, ID 83401
info@firenice.us
sales@firenice.us
firenice.us