



Polaris Axys Intake Vents

Tools:

- #20 (.161") drill bit.
- Cutting tools such as oscillating cutter, step bit or hole saw.
- Deburring tool.

Protector Vents:

1. Remove the stock intakes from the snowmobile. Discard foam inserts.
2. Place a clean cloth inside the intake to prevent debris from entering the airbox.
3. Fit FNI intake vents up to the stock intake housing.
4. Mark drill holes for each intake vent.
5. Use the included template to cut out the inside of the template or drill a series of holes using a step bit.
6. Deburr cutout area.
7. Optional: Place a small bead of silicone or equivalent to the back side of the vent to ensure it is sealed to the stock housing.
8. Install the push rivets one hole at a time. Drill and install one hole at a time and adjust as you work front to back to ensure a perfect fit.
9. Remove any debris from inside the intake.





Please email info@firenice.us if there is any issue with your order.