




### Intake Boost Vent

1. Remove Hood and body panels to access the upper intake plenum.
2. Remove lower plenum to keep debris from entering air intake.
3. Use the provided template to mark cut locations.
4. Cut out, or drill out marked areas.
5. Apply silicone or equivalent to the back side of the Fire N Ice Intake vent to ensure a seal around the vent.
6. Drill out one hole at a time with #21 or 5/32 drill bit, install vent with provided push darts.









Please email [info@firenice.us](mailto:info@firenice.us) if there is any issue with your order.