



Arctic Cat Intake Protectors

Tools:

- #21 or 5/32 drill bit.

Protector Vents:

1. Remove the stock intakes from the snowmobile.
2. Fit FNI intake vents up to the stock intake housing.
3. Mark drill holes for each intake vent.
4. Optional: Place a small bead of silicone or equivalent to the back side of the vent to ensure it is sealed to the stock housing.
5. Drill and install push rivets one hole at a time and adjust as you work front to back to ensure a perfect fit.





Please email info@firenice.us if there is any issue with your order.