



RZR Intake Protectors

Tools:

- #21 or 5/32 drill bit.

Protectors Only:

1. Fit FNI intake vents up to the stock intake housing.
2. Mark drill holes for each intake vent.
3. Drill and install push rivets one hole at a time and adjust as you work front to back to ensure a perfect fit.

Protectors With Prefilter:

1. Remove stock frogskinz material
2. Fit FNI intake vents up to the stock intake housing.
3. Mark drill holes for each intake vent.
4. Optional: Place a small bead of silicone or equivalent to the back side of the vent to ensure it is sealed to the stock housing.
5. Drill and install push rivets one hole at a time and adjust as you work front to back to ensure a perfect fit.





Please email info@firenice.us if there is any issue with your order.