



XP 1000 Inside Extra Intakes

Tools:

- #21 or 5/32 drill bit.
-
1. Fit FNI intake vents up to the stock intake housing.
 2. Mark drill holes for each intake vent. Line up vent to top edge of the intake.
 3. Print templates.
 4. Use cut template to mark cutout locations on the intake.
 5. Drill out corners of the cut area and then cut out the full area using an oscillating cutter.
 6. Optional: Place a small bead of silicone or equivalent to the back side of the vent to ensure it is sealed to the stock housing.
 7. Drill and install push rivets one hole at a time and adjust as you work front to back to ensure a perfect fit.





Please email info@firenice.us if there is any issue with your order.