## Fuformance ...

Fire n Ice Performance Products, LLC 860 Cranmer Ave.
Idaho Falls, ID 83401
info@firenice.us
sales@firenice.us
firenice.us

## 12PSPSK

1-Remove stock side panel devices.

2-Using appropriate cutter (die grinder), cut 6 1" x 7/16" slots as indicated in pix below. (see add. Pix)

3-Drill 1/4" holes in side panel as shown in pix below.

4-Insert rubber straps from inside out.









