



## Ski Doo Gen 5/Summit X Intake Kit (P/N F0375)

■ **NOTE:** Read these instructions thoroughly and carefully before beginning the installation process. Retain these instructions for future reference.

1. Clean and prepare the surface that the adhesive will come in contact with. This can be done with Xylene or Denatured Alcohol. This removes any dirt, oils, or silicone mold release agents.

■ **NOTE:** All adhesive applications must be made at room temperatures and must remain inside for 24 hours before being subject to cold temperatures.

*Removal of stock vents and plastic framework is required for proper installation*

See Fig. 1.

2. Remove half of silicone backing.  
Avoid contact between fingers and adhesive.
3. Align and apply screen to the upper edge of the panel first; then remove the rest of the silicone backing and apply the screen along the edge of the panel down to the bottom edge using the panel edge as a guide. The screen can be removed and repositioned if desired.
4. Press firmly to work out any air bubbles or wrinkles.  
Put stock vent/plastic framework back on for finished product.

See Fig. 2.

Fig. 1



Fig. 2

