



### Matryx Head Light Delete

1. Remove hood.
2. Remove 3 screws holding headlight in. Remove headlight.
3. (If any mesh is covering a hole on the headlight delete parts, drill or puncture the mesh before installing so that the rivet can pass through the hole.)
4. Place head light delete vent in place.
5. Drill with 3/16 bit and rivet first rivet.
6. Drill and rivet one hole at a time, massaging the fit, until all are installed.
7. Repeat on the other side.
8. Reinstall hood.
9. Go ride.



Please email [info@firenice.us](mailto:info@firenice.us) if there is any issue with your order.