



Gen 5 Knee Vent

Tools:

- #20 (.161") drill bit.
- E600 or silicone.

Protector Vents:

1. Remove the knee vent from the snowmobile.
2. Fit FNI intake vents up to the stock intake housing. Align the bottom edge with the matching edge on the stock housing.
3. Optional: Apply a small bead of silicone or equivalent to the inside of the vent and to the intake housing to ensure a complete seal.
4. Drill and install the 2 bottom rivets first.
5. Next drill and install the rivets 1 at a time, working toward the top.
6. Bend the vent around the radius on the stock housing.
7. Then install the top rivets.
8. Reinstall the intake vent onto the snowmobile.
 - a. Note: Some clearance trimming on the side panel might be required when reinstalling the knee vent panel.

Please email info@firenice.us if there is any issue with your order.