



### **Lynx Gen 5 Knee Vent**

#### **Tools:**

- #20 (.161") drill bit.
- E600 or silicone.

#### **Protector Vents:**

1. Remove the knee vent from the snowmobile.
2. Fit FNI intake vents up to the stock intake housing. Align the Top edge with the matching edge on the stock housing.
3. Optional: Apply a small bead of silicone or equivalent to the inside of the vent and to the intake housing to ensure a complete seal.
4. Drill and install the 2 Top rivets first.
5. Next drill and install the rivets 1 at a time, working toward the bottom.
6. Bend the vent around the radius on the stock housing.
7. Then install the bottom rivets.
8. Reinstall the knee vent panel onto the snowmobile.
  - a. Note: Some clearance trimming on the side panel might be required when reinstalling the knee vent panel.

Please email [info@firenice.us](mailto:info@firenice.us) if there is any issue with your order.