



Polaris Matryx Big Air Intakes - Version 2 (Nylon)

Tools:

- T25 Torx

Protector Vents:

1. Remove the stock intakes from the snowmobile using T25 bit.
2. Install Fire N Ice Intakes reusing the screws from Step 1.
3. That's it, you're done.

Please email info@firenice.us if there is any issue with your order.