



SKI-DOO G5 HUV



Vissa hål kan
behöva borrar
upp lite extra

Some might not be fully drilled through,
Drill these holes with a 4.3-4.5mm drill



Nita ihop främre och bakre huvdel på båda sidorna, **EJ** upptill

Rivet the front and back together, if the hood can be sent in one pcs to the customer.



Innan du nitar fast huven upptill,
tryck upp nätväskan och för niten genom nätet så att den fästs och inte ramlar ner på pipan

Rivet the bag to the top of the hood so that it doesn't fall down.
OBS! This step can not be done if the two half are not riveted together, and the customer will then need to do this.



Montering av fästen för insugsgaller

Rivet the 3D printed blocks too the hood. R for Right and L for Left side of the hood

Bottom intake screw

Install the intake vents using the top two screws.

For the bottom intake vent screw, closest to the rider, drill a screw hole using a 3mm (.181") drill bit.



Montering av bakre infästningspunkt. Den avsmalnande sidan ska vara fram mot huvens nos

Mount the rear "clips" to the rear of the hood.
Holes on the left and right are slightly different, so make sure that they align before attaching, only one should fit per side without any drilling.

Gauge Install

Place the gauge in desired location.

Drill a screw hole using a 3mm (.181") drill bit one at a time, installing the screws as you go.

Putsa huven

Clean and polish the hood

Fäst dekalerna enligt bild på båda sidor av huven,
dra försiktigt bort pappen

Attach the chromatic stickers, and put the white stickers in the bag with a card

Lägg i 2 st vita CaribouX dekaler samt ett visitkort i väskan



Mount GPS underneath

Air intake

