



## Catalyst Nose Vents

### Tools:

- #20 (.161") drill bit.
  - E600 or silicone.
1. Remove side panels, hood, and bumper as necessary. Not all rivets can be installed with these items in place. Run as many rivets as you deem necessary to have a satisfactory install.
  2. Leave stock vent material in place. If damaged and you care, replace the frogskin with pieces from arctic cat or use our FNI patch kit.
  3. Fit FNI intake vents up to the nosecone. Align the Notched Top edge with the matching notched edge on the nosecone. Also push the vent as far towards the centerline of the sled as possible.
  4. Optional: Apply a small bead of silicone or equivalent to the inside of the vent and to the intake housing to ensure a complete seal.
  5. Drill and install the 2 Top rivets first. Always be aware of what is behind where you are drilling!
  6. (If your hardware kit included backing washers discard them. They were only included by mistake.)
  7. Next drill and install the rivets 1 at a time, working toward the bottom.
  8. Bend the vent around the radius on the nosecone.
  9. Then install the bottom rivets.
  10. Reinstall panels, hood, and bumper to the snowmobile.



Please email [info@firenice.us](mailto:info@firenice.us) if there is any issue with your order.